



1: Place lining into lid for fitment.



2: Pictured above are 2 lids. L Side is on 1993-2004 models. R Side is 2005+. (Now is the time to make sure you have the correct kit for a precise fit.)



3: If you are leaving the seal on, mask it! Spray the lid with plenty of adhesive!



4: Push seams together. After it is dry, run finger along seam area to fluff up the lining.



5: Make sure your rubber mounting grommets are back in place.



Routine cleaning can be done with a damp cloth.
Stains may be removed with a rug cleaner!

**We have lining kits for
Tour Packs also!**

- Item # 8790 Charcoal 1993-2004
- Item # 8791 Charcoal 2005 and up
- Item # 8792 Silver 1993-2004
- Item # 8793 Silver 2005 and up
- Item # 8798 Extended Bags 2014 and up

**ALL products 100%
Made in the USA**

SUMAX Cycle Products 122 Clear Road Oriskany, NY 13424 (315)768-1058

