


Putting Bags back together after PAINT

Front Stainless Hinge goes on the inside of the lid and bag. Hinge should be level.



Beetle Keeper goes on the inside of the bag. You can adjust this up and down to hold the lid firmer into place upon closing.

Push button Lock/Latch drops in from the top. Add stainless washer then black nut to hold firmly into place.



Stainless Stay goes on the inside of the bag.



Attach the trim lock edge with adhesive. Run it from the front of the bag by the hinge around bag. If lid does not come down directly over the bag adjust the stay by pushing it in or out. Make sure hinge is level. Liner may be cleaned with soap & water. Sumax 315-768-1058